

Control Center

Tier Introduction



What are Control Center Tiers?

IndigoVision's Control Center is available for purchase in three tiered offerings.

How you choose is dependent on your systems' requirements.




Control Center Tier Overview



Control Center Tier Feature Overview

	INDIGO ULTRA		INDIGO LITE®
Real Time Monitoring	ONVIF PTZ Priority Connect to CyberVigilant®* Connect to Video Wall*	Sequences Salvos Guard Towers Maps 3 rd Party Systems Advanced Analytics CyberVigilant® in Cameras	Live Video & Audio PTZ Control & Presets Control Center Mobile
Alarm Management	Detector: Double Knock/ Unhandled Alarm	Detector: External Alarm Escalation	Alarm Actions/Groups Detector: Fault/Basic Analytics/Digital Input
Post Event Monitoring	Al Powered by BriefCam* Bookmarks Failover Recording/Redundancy Automatic NVR Switching	NVR Footage Retrieval	Playback Thumbnails Export Recording Audio Bookmarks Edge Storage Retrieval
System Administration & Security	Segmented Databases	Windows User Authentication	User Management & Permissions Audit Log System Monitoring Digital Watermarking

Choosing the right Tier for you



All tiers provide unlimited client workstations and connected NVR's, outside of this you should establish which features you need and the number of devices required for your security system.

Device Connections

What happens if you outgrow your Tier?

MANAGEMENT SOCTOWARE IndepULTRA® IndepRO® IndepRO® IndepRO® IndepRO® IndepCITE® CAMERAS GX Range BX Range Ultra Range

Each Control Center tier is future-proofed meaning:



IndigoVision's DNA reliably supports any system scale across the product portfolio.



Smoothly upgrade to higher software tiers within Control Center.



You can easily add cameras and storage, 'Mix & Match' where required.

Any Questions?